




C2R2 Max

Version 02 – 02 April 2009

G31


CLUTCH CABLE



! Remember to free the upper end stop (B) and the bottom end stop (A) of the pedal before fitting, so that the cable is not constrained during fitting.



Fit the cable on the clutch pedal, the plastic cable stop on the pedal support, and the panel grommet on the fire-wall



G31
Clutch Cable



L
ORDER